

# TABLE OF CONTENTS

---



## Chapter 1: Getting Started

<b>Introduction</b> .....	1-2
The Purpose of this Manual.....	1-2
Supplemental Manuals.....	1-2
Technical Support.....	1-2
<b>Conventions Used</b> .....	1-3
Key Topics for Each Chapter.....	1-3
<b>DL06 Micro PLC Overview</b> .....	1-4
The DL06 PLC Features.....	1-4
DirectSOFT Programming for Windows™.....	1-4
Handheld Programmer.....	1-5
<b>I/O Quick Selection Guide</b> .....	1-5
<b>Quick Start</b> .....	1-6
<b>Steps to Designing a Successful System</b> .....	1-10
<b>Questions and Answers about DL06 Micro PLCs</b> .....	1-12

## Chapter 2: Installation, Wiring, and Specifications

<b>Safety Guidelines</b> .....	2-2
Plan for Safety.....	2-2
Three Levels of Protection.....	2-3
Emergency Stops.....	2-3
Emergency Power Disconnect.....	2-4
Orderly System Shutdown.....	2-4
Class 1, Division 2 Approval.....	2-4
<b>Orientation to DL06 Front Panel</b> .....	2-5
Terminal Block Removal.....	2-6

## Table of Contents

---

<b>Mounting Guidelines</b> .....	<b>2-7</b>
Unit Dimensions.....	2-7
Enclosures .....	2-7
Panel Layout & Clearances .....	2-8
Using Mounting Rails .....	2-9
Environmental Specifications.....	2-10
Agency Approvals.....	2-10
Marine Use.....	2-10
<b>Wiring Guidelines</b> .....	<b>2-11</b>
External Power Source.....	2-12
Planning the Wiring Routes.....	2-12
Fuse Protection for Input and Output Circuits.....	2-13
I/O Point Numbering .....	2-13
<b>System Wiring Strategies</b> .....	<b>2-14</b>
PLC Isolation Boundaries .....	2-14
Connecting Operator Interface Devices.....	2-15
Connecting Programming Devices .....	2-15
Sinking / Sourcing Concepts .....	2-16
I/O “Common” Terminal Concepts.....	2-17
Connecting DC I/O to “Solid State” Field Devices.....	2-18
Solid State Input Sensors.....	2-18
Solid State Output Loads.....	2-18
Relay Output Wiring Methods.....	2-20
Relay Outputs-Transient Suppression For Inductive Loads in a Control System.....	2-21
Prolonging Relay Contact Life .....	2-26
DC Input Wiring Methods.....	2-27
DC Output Wiring Methods.....	2-28
High-Speed I/O Wiring Methods.....	2-29
<b>Wiring Diagrams and Specifications</b> .....	<b>2-30</b>
D0-06AA I/O Wiring Diagram.....	2-30
D0-06AR I/O Wiring Diagram .....	2-32
D0-06DA I/O Wiring Diagram .....	2-34
D0-06DD1 I/O Wiring Diagram.....	2-36
D0-06DD2 I/O Wiring Diagram.....	2-38
D0-06DR I/O Wiring Diagram.....	2-40
D0-06DD1-D I/O Wiring Diagram.....	2-42

D0-06DD2-D I/O Wiring Diagram.....	2-44
D0-06DR-D I/O Wiring Diagram .....	2-46
<b>Glossary of Specification Terms .....</b>	<b>2-48</b>

## Chapter 3: CPU Specifications and Operation

### Overview 3-2

DL06 CPU Features .....	3-2
-------------------------	-----

### CPU Specifications..... 3-3

### CPU Hardware Setup..... 3-4

Communication Port Pinout Diagrams .....	3-4
--	-----

Connecting the Programming Devices.....	3-5
---	-----

CPU Setup Information .....	3-5
-----------------------------	-----

Status Indicators.....	3-6
------------------------	-----

Mode Switch Functions.....	3-6
----------------------------	-----

Changing Modes in the DL06 PLC .....	3-7
--------------------------------------	-----

Mode of Operation at Power-up .....	3-7
-------------------------------------	-----

### Using Battery Backup ..... 3-8

Battery Backup .....	3-8
----------------------	-----

Auxiliary Functions .....	3-9
---------------------------	-----

Clearing an Existing Program .....	3-9
------------------------------------	-----

Initializing System Memory .....	3-9
----------------------------------	-----

Setting Retentive Memory Ranges.....	3-10
--------------------------------------	------

Using a Password .....	3-11
------------------------	------

### CPU Operation..... 3-12

CPU Operating System.....	3-12
---------------------------	------

Program Mode.....	3-13
-------------------	------

Run Mode .....	3-13
----------------	------

Read Inputs .....	3-14
-------------------	------

Service Peripherals and Force I/O .....	3-14
---	------

CPU Bus Communication .....	3-15
-----------------------------	------

Update Clock, Special Relays and Special Registers.....	3-15
---	------

Solve Application Program .....	3-16
---------------------------------	------

Solve PID Loop Equations.....	3-16
-------------------------------	------

Write Outputs .....	3-16
---------------------	------

## Table of Contents

---

Write Outputs to Specialty I/O .....	3-16
Diagnostics.....	3-17
<b>I/O Response Time .....</b>	<b>3-17</b>
Is Timing Important for Your Application?.....	3-17
Normal Minimum I/O Response.....	3-18
Normal Maximum I/O Response .....	3-18
Improving Response Time .....	3-19
<b>CPU Scan Time Considerations.....</b>	<b>3-20</b>
Reading Inputs .....	3-20
Writing Outputs .....	3-20
Service Peripherals.....	3-21
CPU Bus Communication .....	3-21
Update Clock/Calendar, Special Relays, Special Registers .....	3-21
Application Program Execution .....	3-22
PLC Numbering Systems.....	3-23
PLC Resources .....	3-23
V-Memory .....	3-24
Binary-Coded Decimal Numbers .....	3-24
Hexadecimal Numbers .....	3-24
<b>Memory Map .....</b>	<b>3-25</b>
Octal Numbering System .....	3-25
Discrete and Word Locations.....	3-25
V-memory Locations for Discrete Memory Areas .....	3-25
Input Points (X Data Type).....	3-26
Output Points (Y Data Type) .....	3-26
Control Relays (C Data Type) .....	3-26
Timers and Timer Status Bits (T Data Type).....	3-26
Timer Current Values (V Data Type).....	3-27
Counters and Counter Status Bits (CT Data type).....	3-27
Counter Current Values (V Data Type) .....	3-27
Word Memory (V Data Type).....	3-28
Stages (S Data type).....	3-28
Special Relays (SP Data Type).....	3-28
<b>DL06 System V-memory .....</b>	<b>3-29</b>
System Parameters and Default Data Locations (V Data Type) .....	3-29

DL06 Aliases .....	3-31
DL06 Memory Map.....	3-32
X Input/Y Output Bit Map .....	3-33
Stage Control/Status Bit Map.....	3-34
Control Relay Bit Map .....	3-36
Timer Status Bit Map.....	3-38
Counter Status Bit Map.....	3-38
GX and GY I/O Bit Map .....	3-39

## Chapter 4: System Design and Configuration

<b>DL06 System Design Strategies .....</b>	<b>4-2</b>
I/O System Configurations .....	4-2
Networking Configurations .....	4-2
<b>Module Placement.....</b>	<b>4-3</b>
Slot Numbering.....	4-3
Automatic I/O Configuration.....	4-4
Manual I/O Configuration .....	4-4
<b>Power Budgeting.....</b>	<b>4-5</b>
Power supplied .....	4-5
Power required by base unit .....	4-5
Power required by option cards .....	4-5
<b>Configuring the DL06's Comm Ports.....</b>	<b>4-7</b>
DL06 Port Specifications.....	4-7
DL06 Port Pinouts .....	4-7
Choosing a Network Specification.....	4-8
RS-232 Network.....	4-8
RS-422 Network.....	4-8
RS-485 Network.....	4-8
<b>Connecting to MODBUS and DirectNET Networks.....</b>	<b>4-9</b>
MODBUS Port Configuration.....	4-9
DirectNET Port Configuration.....	4-10
<b>Non-Sequence Protocol (ASCII In/Out and PRINT).....</b>	<b>4-11</b>
Non-Sequence Port Configuration.....	4-11

<b>Network Slave Operation</b> .....	<b>4-12</b>
MODBUS Function Codes Supported.....	4-12
Determining the MODBUS Address.....	4-12
If Your Host Software Requires the Data Type and Address .....	4-13
Example 1: V2100.....	4-14
Example 2: Y20.....	4-14
Example 3: T10 Current Value.....	4-14
Example 4: C54.....	4-14
If Your MODBUS Host Software Requires an Address ONLY .....	4-15
Example 1: V2100 584/984 Mode .....	4-16
Example 2: Y20 584/984 Mode .....	4-16
Example 3: T10 Current Value 484 Mode .....	4-17
Example 4: C54 584/984 Mode.....	4-17
<b>Network Master Operation</b> .....	<b>4-17</b>
Step 1: Identify Master Port # and Slave #.....	4-18
Step 2: Load Number of Bytes to Transfer.....	4-18
Step 3: Specify Master Memory Area.....	4-19
Step 4: Specify Slave Memory Area .....	4-20
Communications from a Ladder Program.....	4-21
Multiple Read and Write Interlocks.....	4-21
<b>Network Master Operation (using MRX and MWX Instructions)</b> .....	<b>4-22</b>
MODBUS Function Codes Supported.....	4-22
MODBUS Read from Network(MRX) .....	4-23
MRX Slave Memory Address.....	4-24
MRX Master Memory Addresses.....	4-24
MRX Number of Elements.....	4-24
MRX Exception Response Buffer .....	4-24
MODBUS Write to Network (MWX) .....	4-25
MWX Slave Memory Address .....	4-26
MWX Master Memory Addresses.....	4-26
MWX Number of Elements.....	4-26
MWX Exception Response Buffer.....	4-26
MRX/MWX Example in DirectSOFT .....	4-27
Multiple Read and Write Interlocks.....	4-27

## Chapter 5: Standard RLL Instructions

<b>Introduction</b> .....	5-2
<b>Using Boolean Instructions</b> .....	5-5
END Statement .....	5-5
Simple Rungs .....	5-5
Normally Closed Contact .....	5-6
Contacts in Series.....	5-6
Midline Outputs.....	5-6
Parallel Elements.....	5-7
Joining Series Branches in Parallel.....	5-7
Joining Parallel Branches in Series.....	5-7
Combination Networks .....	5-7
Comparative Boolean .....	5-8
Boolean Stack.....	5-8
Immediate Boolean .....	5-9
<b>Boolean Instructions</b> .....	5-10
<b>Comparative Boolean</b> .....	5-26
<b>Immediate Instructions</b> .....	5-32
<b>Timer, Counter and Shift Register Instructions</b> .....	5-39
Using Timers .....	5-39
Timer Example Using Discrete Status Bits .....	5-41
Timer Example Using Comparative Contacts.....	5-41
Accumulating Timer Example using Discrete Status Bits .....	5-43
Accumulator Timer Example Using Comparative Contacts .....	5-43
Using Counters.....	5-44
Counter Example Using Discrete Status Bits .....	5-46
Counter Example Using Comparative Contacts .....	5-46
Stage Counter Example Using Discrete Status Bits.....	5-48
Stage Counter Example Using Comparative Contacts .....	5-48
Up / Down Counter Example Using Discrete Status Bits.....	5-50
Up / Down Counter Example Using Comparative Contacts.....	5-50
<b>Accumulator/Stack Load and Output Data Instructions</b> .....	5-52
Using the Accumulator.....	5-52
Copying Data to the Accumulator.....	5-52

## Table of Contents

---

Changing the Accumulator Data .....	5-53
Using the Accumulator Stack.....	5-54
Using Pointers .....	5-55
<b>Logical Instructions (Accumulator) .....</b>	<b>5-69</b>
<b>Math Instructions .....</b>	<b>5-86</b>
<b>Transcendental Functions.....</b>	<b>5-118</b>
<b>Bit Operation Instructions.....</b>	<b>5-120</b>
<b>Number Conversion Instructions (Accumulator).....</b>	<b>5-127</b>
Shuffle Digits Block Diagram .....	5-139
<b>Table Instructions .....</b>	<b>5-141</b>
Copy Data From a Data Label Area to V-memory.....	5-143
<b>Clock/Calendar Instructions .....</b>	<b>5-171</b>
<b>CPU Control Instructions.....</b>	<b>5-173</b>
<b>Program Control Instructions .....</b>	<b>5-175</b>
<b>Interrupt Instructions .....</b>	<b>5-183</b>
<b>Message Instructions.....</b>	<b>5-186</b>
Move Block Instruction (MOVBLK) .....	5-189
Copy Data From a Data Label Area to V-memory.....	5-189
<b>Intelligent I/O Instructions.....</b>	<b>5-194</b>
Read from Intelligent Module (RD).....	5-194
Write to Intelligent Module (WT) .....	5-195
<b>Network Instructions .....</b>	<b>5-196</b>
Direct Text Entry .....	5-200
Embedding date and/or time variables.....	5-201
Embedding V-memory data .....	5-201
Data Format Suffixes for Embedded V-memory Data.....	5-202
Text Entry from V-memory.....	5-203
<b>MODBUS RTU Instructions .....</b>	<b>5-204</b>
MRX Slave Address Ranges.....	5-205
MWX Slave Address Ranges.....	5-208
MWX Master Memory Address Ranges.....	5-208
MWX Number of Elements .....	5-208
MWX Exception Response Buffer.....	5-208



<b>ASCII Instructions</b> .....	<b>5-210</b>
Reading ASCII Input Strings.....	5-210
Writing ASCII Output Strings.....	5-210
Managing the ASCII Strings .....	5-211
<b>Intelligent Box (IBox) Instructions</b> .....	<b>5-230</b>

## Chapter 6: Drum Instruction Programming

<b>Introduction</b> .....	<b>6-2</b>
Purpose .....	6-2
Drum Terminology.....	6-2
Drum Chart Representation.....	6-3
Output Sequences.....	6-3
<b>Step Transitions</b> .....	<b>6-4</b>
Drum Instruction Types .....	6-4
Timer-Only Transitions .....	6-4
Timer and Event Transitions .....	6-5
Event-Only Transitions.....	6-6
Counter Assignments .....	6-6
Last Step Completion .....	6-7
<b>Overview of Drum Operation</b> .....	<b>6-8</b>
Drum Instruction Block Diagram .....	6-8
Powerup State of Drum Registers .....	6-9
<b>Drum Control Techniques</b> .....	<b>6-10</b>
Drum Control Inputs.....	6-10
Self-Resetting Drum.....	6-11
Initializing Drum Outputs.....	6-11
Using Complex Event Step Transitions .....	6-11
<b>Drum Instruction</b> .....	<b>6-12</b>
Timed Drum with Discrete Outputs (DRUM).....	6-12
Event Drum (EDRUM) .....	6-14
Handheld Programmer Drum Mnemonics.....	6-16
Masked Event Drum with Discrete Outputs (MDRMD).....	6-19
Masked Event Drum with Word Output (MDRMW) .....	6-21

## Chapter 7: RLL<sup>PLUS</sup> Stage Programming

<b>Introduction to Stage Programming</b> .....	7-2
Overcoming “Stage Fright” .....	7-2
<b>Learning to Draw State Transition Diagrams</b> .....	7-3
Introduction to Process States .....	7-3
The Need for State Diagrams .....	7-3
A 2-State Process .....	7-3
RLL Equivalent .....	7-4
Stage Equivalent .....	7-4
Let’s Compare .....	7-5
Initial Stages .....	7-5
What Stage Bits Do .....	7-6
Stage Instruction Characteristics .....	7-6
<b>Using the Stage Jump Instruction for State Transitions</b> .....	7-7
Stage Jump, Set, and Reset Instructions .....	7-7
<b>Stage Program Example: Toggle On/Off Lamp Controller</b> .....	7-8
A 4-State Process .....	7-8
<b>Four Steps to Writing a Stage Program</b> .....	7-9
1. Write a Word Description of the application. ....	7-9
2. Draw the Block Diagram. ....	7-9
3. Draw the State Transition Diagram. ....	7-9
4. Write the Stage Program .....	7-9
<b>Stage Program Example: A Garage Door Opener</b> .....	7-10
Garage Door Opener Example .....	7-10
Draw the Block Diagram .....	7-10
Draw the State Diagram .....	7-11
Add Safety Light Feature .....	7-12
Modify the Block Diagram and State Diagram .....	7-12
Using a Timer Inside a Stage .....	7-13
Add Emergency Stop Feature .....	7-14
Exclusive Transitions .....	7-14
<b>Stage Program Design Considerations</b> .....	7-15
Stage Program Organization .....	7-15
How Instructions Work Inside Stages .....	7-16

Using a Stage as a Supervisory Process..... 7-17

Stage Counter ..... 7-17

Power Flow Transition Technique..... 7-18

Stage View in DirectSOFT..... 7-18

**Parallel Processing Concepts..... 7-19**

Parallel Processes ..... 7-19

Converging Processes..... 7-19

Convergence Stages (CV)..... 7-19

Convergence Jump (CVJMP)..... 7-20

Convergence Stage Guidelines ..... 7-20

**RLL<sup>PLUS</sup> (Stage) Instructions ..... 7-21**

Stage (SG)..... 7-21

Initial Stage (ISG) ..... 7-22

Jump (JMP)..... 7-22

Not Jump (NJMP)..... 7-22

Converge Stage (CV) and Converge Jump (CVJMP) ..... 7-23

Block Call (BCALL)..... 7-25

Block (BLK)..... 7-25

Block End (BEND)..... 7-25

**Questions and Answers about Stage Programming ..... 7-27**

## Chapter 8: PID Loop Operation

**DL06 PID Control..... 8-2**

DL06 PID Control Features ..... 8-2

**Introduction to PID Control..... 8-4**

What is PID Control? ..... 8-4

**Introducing DL06 PID Control ..... 8-6**

Process Control Definitions..... 8-8

**PID Loop Operation..... 8-9**

Position Form of the PID Equation..... 8-9

Reset Windup Protection ..... 8-10

Freeze Bias ..... 8-11

Adjusting the Bias..... 8-11

Step Bias Proportional to Step Change in SP ..... 8-12

## Table of Contents

---

Eliminating Proportional, Integral or Derivative Action .....	8-12
Velocity Form of the PID Equation.....	8-12
Bumpless Transfer .....	8-13
Loop Alarms .....	8-13
Loop Operating Modes .....	8-14
Special Loop Calculations .....	8-14
<b>Ten Steps to Successful Process Control.....</b>	<b>8-16</b>
<b>PID Loop Setup.....</b>	<b>8-18</b>
Some Things to Do and Know Before Starting .....	8-18
PID Error Flags.....	8-18
Establishing the Loop Table Size and Location .....	8-18
Loop Table Word Definitions.....	8-20
PID Mode Setting 1 Bit Descriptions (Addr + 00) .....	8-21
PID Mode Setting 2 Bit Descriptions (Addr + 01) .....	8-22
Mode/Alarm Monitoring Word (Addr + 06) .....	8-23
Ramp/Soak Table Flags (Addr + 33) .....	8-23
Ramp/Soak Table Location (Addr + 34).....	8-24
Ramp/Soak Table Programming Error Flags (Addr + 35).....	8-24
Configure the PID Loop.....	8-25
<b>PID Loop Tuning.....</b>	<b>8-40</b>
Open-Loop Test .....	8-40
Manual Tuning Procedure .....	8-41
Alternative Manual Tuning Procedures by Others.....	8-44
Tuning PID Controllers .....	8-44
Auto Tuning Procedure .....	8-45
Use DirectSOFT 5 Data View with PID View .....	8-49
Open a New Data View Window.....	8-49
Open PID View.....	8-50
<b>Using the Special PID Features .....</b>	<b>8-53</b>
How to Change Loop Modes .....	8-53
Operator Panel Control of PID Modes .....	8-54
PLC Modes Effect on Loop Modes.....	8-54
Loop Mode Override.....	8-54
PV Analog Filter.....	8-55
Creating an Analog Filter in Ladder Logic.....	8-56

Use the <i>DirectSOFT</i> Filter Intelligent Box Instructions .....	8-57
FilterB Example.....	8-57
<b>Ramp/Soak Generator .....</b>	<b>8-58</b>
Introduction .....	8-58
Ramp/Soak Table .....	8-59
Ramp/Soak Table Flags.....	8-61
Ramp/Soak Generator Enable .....	8-61
Ramp/Soak Controls.....	8-61
Ramp/Soak Profile Monitoring.....	8-62
Ramp/Soak Programming Errors.....	8-62
Testing Your Ramp/Soak Profile.....	8-62
<b><i>DirectSOFT</i> Ramp/Soak Example .....</b>	<b>8-63</b>
Setup the Profile in PID Setup .....	8-63
Program the Ramp/Soak Control in Relay Ladder .....	8-63
Test the Profile .....	8-64
<b>Cascade Control.....</b>	<b>8-65</b>
Introduction .....	8-65
Cascaded Loops in the DL06 CPU .....	8-66
Tuning Cascaded Loops .....	8-67
<b>Time-Proportioning Control.....</b>	<b>8-68</b>
On/Off Control Program Example .....	8-69
<b>Feedforward Control .....</b>	<b>8-70</b>
Feedforward Example.....	8-71
<b>PID Example Program .....</b>	<b>8-72</b>
Program Setup for the PID Loop .....	8-72
<b>Troubleshooting Tips.....</b>	<b>8-75</b>
<b>Glossary of PID Loop Terminology .....</b>	<b>8-77</b>
<b>Bibliography .....</b>	<b>8-79</b>

## Chapter 9: Maintenance and Troubleshooting

Hardware System Maintenance .....	9-2
Standard Maintenance .....	9-2
<b>Diagnostics.....</b>	<b>9-2</b>

## Table of Contents

---

Diagnostics.....	9-2
Fatal Errors .....	9-2
Non-fatal Errors .....	9-2
V-memory Error Code Locations.....	9-3
Special Relays (SP) Corresponding to Error Codes .....	9-3
DL06 Micro PLC Error Codes.....	9-4
Program Error Codes.....	9-5
<b>CPU Indicators .....</b>	<b>9-6</b>
PWR Indicator .....	9-6
RUN Indicator .....	9-7
CPU Indicator.....	9-7
<b>Communications Problems .....</b>	<b>9-7</b>
<b>I/O Point Troubleshooting.....</b>	<b>9-8</b>
Possible Causes .....	9-8
Some Quick Steps .....	9-8
Handheld Programmer Keystrokes Used to Test an Output Point.....	9-9
<b>Noise Troubleshooting .....</b>	<b>9-10</b>
Electrical Noise Problems.....	9-10
Reducing Electrical Noise.....	9-10
<b>Machine Startup and Program Troubleshooting .....</b>	<b>9-11</b>
Syntax Check .....	9-11
Special Instructions.....	9-12
Duplicate Reference Check.....	9-13
Run Time Edits .....	9-14
Run Time Edit Example .....	9-15
Forcing I/O Points .....	9-16
Regular Forcing with Direct Access.....	9-18
Bit Override Forcing .....	9-19
Bit Override Indicators.....	9-19
Reset the PLC to Factory Defaults.....	9-20

## Chapter 10: LCD Display Panel

Introduction to the DL06 LCD Display Panel .....	10-2
Keypad .....	10-2

<b>Snap-in installation</b> .....	10-3
<b>Display Priority</b> .....	10-4
<b>Menu Navigation</b> .....	10-5
<b>Confirm PLC Type, Firmware Revision Level, Memory Usage, Etc.</b> .....	10-6
<b>Examining Option Slot Contents</b> .....	10-8
Menu 2, M2:SYSTEM CFG. ....	10-8
<b>Monitoring and Changing Data Values</b> .....	10-10
Menu 3, M3:MONITOR .....	10-10
Data Monitor .....	10-10
V-memory values.....	10-10
Pointer values.....	10-12
<b>Bit Monitor</b> .....	10-13
Bit status .....	10-13
<b>Changing Date and Time</b> .....	10-14
Menu 4, M4 : CALENDAR R/W.....	10-14
<b>Setting Password and Locking</b> .....	10-17
Menu 5, M5 : PASSWORD R/W.....	10-17
<b>Reviewing Error History</b> .....	10-20
Menu 6, M6 : ERR HISTORY .....	10-20
<b>Toggle Light and Beeper, Test Keys</b> .....	10-21
Menu 7, M7 : LCD TEST&SET .....	10-21
<b>PLC Memory Information for the LCD Display Panel</b> .....	10-22
Data Format Suffixes for Embedded V-memory Data.....	10-22
Reserved memory registers for the LCD Display Panel.....	10-23
V7742 bit definitions.....	10-24
<b>Changing the Default Screen</b> .....	10-25
Example program for setting the default screen message.....	10-25
<b>DL06 LCD Display Panel Instruction (LCD)</b> .....	10-26
Source of message .....	10-26
ASCII Character Codes .....	10-27
Example program: alarm with embedded date/time stamp .....	10-28
Example program: alarm with embedded V-memory data .....	10-29
Example program: alarm text from V-memory with embedded V-memory data ..	10-30

### Appendix A: Auxiliary Functions

<b>Introduction</b> .....	<b>A-2</b>
Purpose of Auxiliary Functions.....	A-2
Accessing AUX Functions via DirectSOFT.....	A-3
Accessing AUX Functions via the Handheld Programmer.....	A-3
<b>AUX 2* — RLL Operations</b> .....	<b>A-4</b>
AUX 21 Check Program .....	A-4
AUX 22 Change Reference .....	A-4
AUX 23 Clear Ladder Range .....	A-4
AUX 24 Clear Ladders .....	A-4
<b>AUX 3* — V-memory Operations</b> .....	<b>A-4</b>
AUX 31 Clear V-memory .....	A-4
<b>AUX 4* — I/O Configuration</b> .....	<b>A-5</b>
AUX 41 Show I/O Configuration .....	A-5
<b>AUX 5* — CPU Configuration</b> .....	<b>A-5</b>
AUX 51 Modify Program Name.....	A-5
AUX 53 Display Scan Time .....	A-5
AUX 54 Initialize Scratchpad .....	A-5
AUX 55 Set Watchdog Timer .....	A-5
AUX 56 CPU Network Address .....	A-6
AUX 57 Set Retentive Ranges .....	A-6
AUX 58 Test Operations.....	A-6
AUX 59 Bit Override.....	A-7
AUX 5B Counter Interface Configuration.....	A-7
AUX 5D Select PLC Scan Mode .....	A-7
<b>AUX 6* — Handheld Programmer Configuration</b> .....	<b>A-8</b>
AUX 61 Show Revision Numbers.....	A-8
AUX 62 Beeper On/Off.....	A-8
AUX 65 Run Self Diagnostics .....	A-8
<b>AUX 7* — EEPROM Operations</b> .....	<b>A-8</b>
Transferable Memory Areas .....	A-8
AUX 71 CPU to HPP EEPROM.....	A-8
AUX 72 HPP EEPROM to CPU.....	A-9
AUX 73 Compare HPP EEPROM to CPU .....	A-9



AUX 74 HPP EEPROM Blank Check.....A-9  
 AUX 75 Erase HPP EEPROM.....A-9  
 AUX 76 Show EEPROM Type.....A-9  
**AUX 8\* — Password Operations .....A-9**  
 AUX 81 Modify Password .....A-9  
 AUX 82 Unlock CPU.....A-10  
 AUX 83 Lock CPU.....A-10

**Appendix B: DL06 Error codes**

**DL06 Error Codes.....B-2**

**Appendix C: Instruction Execution Times**

**Introduction .....C-2**  
 V-Memory Data Registers .....C-2  
 V-Memory Bit Registers .....C-2  
 How to Read the Tables .....C-2  
**Instruction Execution Times .....C-3**  
 Boolean Instructions .....C-3  
 Comparative Boolean Instructions .....C-4  
 Immediate Instructions.....C-11  
 Bit of Word Boolean Instructions .....C-12  
 Timer, Counter and Shift Register.....C-13  
 Accumulator Data Instructions .....C-14  
 Logical Instructions.....C-15  
 Math Instructions .....C-16  
 Differential Instructions .....C-19  
 Bit Instructions .....C-19  
 Number Conversion Instructions .....C-20  
 Table Instructions.....C-20  
 CPU Control Instructions.....C-22  
 Program Control Instructions .....C-22  
 Interrupt Instructions.....C-22  
 Network Instructions .....C-22  
 Intelligent I/O Instructions.....C-23  
 Message Instructions.....C-23

## Table of Contents

---

RLL <sup>PLUS</sup> Instructions.....	C-23
Drum Instructions .....	C-23
Clock/Calendar Instructions.....	C-24
MODBUS Instructions.....	C-24
ASCII Instructions .....	C-24

## Appendix D: Special Relays

<b>DL06 PLC Special Relays</b> .....	<b>D-2</b>
Startup and Real-Time Relays .....	D-2
CPU Status Relays.....	D-2
System Monitoring.....	D-3
Accumulator Status .....	D-3
HSIO Input Status.....	D-4
HSIO Pulse Output Relay .....	D-4
Communication Monitoring Relay.....	D-4
Option Slot Communication Monitoring Relay.....	D-4
Option Slot Special Relay .....	D-4
Counter 1 Mode 10 Equal Relays .....	D-5
Counter 2 Mode 10 Equal Relays .....	D-6

## Appendix E: High-speed Input and Pulse Output Features

<b>Introduction</b> .....	<b>E-2</b>
Built-in Motion Control Solution .....	E-2
Availability of HSIO Features.....	E-2
Dedicated High- Speed I/O Circuit.....	E-3
Wiring Diagrams for Each HSIO Mode .....	E-3
<b>Choosing the HSIO Operating Mode</b> .....	<b>E-4</b>
Understanding the Six Modes .....	E-4
Default Mode.....	E-5
Configuring the HSIO Mode .....	E-6
Configuring Inputs X0 – X3.....	E-6
<b>Mode 10: High-Speed Counter</b> .....	<b>E-7</b>
Purpose .....	E-7
Functional Block Diagram.....	E-7
Wiring Diagram.....	E-8
Interfacing to Counter Inputs .....	E-8

Setup for Mode 10.....	E-9
Presets and Special Relays .....	E-9
Absolute and Incremental Presets.....	E-10
Preset Data Starting Location .....	E-11
Using Fewer than 24 Presets .....	E-11
Equal Relay Numbers .....	E-12
Calculating Your Preset Values.....	E-13
X Input Configuration .....	E-14
Writing Your Control Program.....	E-15
Program Example 1: Counter Without Presets.....	E-16
Program Example 2: Counter With Presets .....	E-18
Program Example 3: Counter With Preload .....	E-21
Troubleshooting Guide for Mode 10 .....	E-23
Symptom: The counter does not count.....	E-23
Symptom: The counter counts but the presets do not function. ....	E-23
Symptom: The counter counts up but will not reset. ....	E-23
<b>Mode 20: Up/Down Counter .....</b>	<b>E-24</b>
Purpose.....	E-24
Functional Block Diagram.....	E-24
Quadrature Encoder Signals .....	E-25
Wiring Diagram.....	E-25
Interfacing to Encoder Outputs .....	E-26
Setup for Mode 20.....	E-27
Presets and Special Relays .....	E-27
X Input Configuration .....	E-28
Mode 20 Up/Down Counter .....	E-28
Writing Your Control Program.....	E-29
Program Example 1: Quadrature Counting with an Interrupt.....	E-30
Program Example 2: Up/Down Counting with Standard Inputs .....	E-32
Program Example 3: Quadrature Counting .....	E-34
Troubleshooting Guide for Mode 20 .....	E-37
Symptom: The counter does not count.....	E-37
Symptom: The counter counts in the wrong direction .....	E-37
Symptom: The counter counts up and down but will not reset.....	E-37

<b>Mode 30: Pulse Output</b> .....	<b>E-38</b>
Purpose .....	E-38
Functional Block Diagram.....	E-39
Wiring Diagram.....	E-40
Interfacing to Drive Inputs.....	E-40
Motion Profile Specifications .....	E-41
Physical I/O Configuration.....	E-41
Logical I/O Functions .....	E-41
Setup for Mode 30.....	E-42
Profile/Velocity Select Register.....	E-43
Profile Parameter Table.....	E-43
Automatic Trapezoidal Profile.....	E-43
Step Trapezoidal Profile.....	E-44
Velocity Control .....	E-44
Step Trapezoidal Profile.....	E-44
Choosing the Profile Type .....	E-45
Automatic Trapezoidal Profile Defined.....	E-45
Step Trapezoidal Profiles Defined .....	E-46
Velocity Control Defined .....	E-46
Automatic Trapezoidal Profile Operation .....	E-47
Program Example 1: Automatic Trapezoidal Profile without External Interrupt.....	E-48
Preload Position Value .....	E-49
Program Example 2: Automatic Trapezoidal Profile with External Interrupt .....	E-50
Program Example 3: Automatic Trapezoidal Profile with Home Search.....	E-53
Step Trapezoidal Profile Operation .....	E-58
Program Example 4: Step Trapezoidal Profile .....	E-59
Velocity Profile Operation.....	E-62
Program Example 5: Velocity Profile.....	E-63
Automatic Trapezoidal Profile Error Codes.....	E-65
Troubleshooting Guide for Mode 30.....	E-65
Symptom: The stepper motor does not rotate. ....	E-65
Symptom: The motor turns in the wrong direction.....	E-66
<b>Mode 40: High-Speed Interrupts</b> .....	<b>E-67</b>
Purpose .....	E-67
Functional Block Diagram.....	E-67
Setup for Mode 40.....	E-68

Interrupts and the Ladder Program .....	E-68
External Interrupt Timing Parameters .....	E-69
Timed Interrupt Parameters.....	E-69
X Input/Timed INT Configuration .....	E-69
Program Example 1: External Interrupt .....	E-70
Program Example 2: Timed Interrupt .....	E-71
<b>Mode 50: Pulse Catch Input.....</b>	<b>E-72</b>
Purpose.....	E-72
Functional Block Diagram.....	E-72
Pulse Catch Timing Parameters .....	E-72
Setup for Mode 50.....	E-73
X Input Configuration .....	E-74
Program Example 1: Pulse Catch .....	E-75
<b>Mode 60: Discrete Inputs with Filter .....</b>	<b>E-76</b>
Purpose.....	E-76
Functional Block Diagram.....	E-76
Input Filter Timing Parameters .....	E-76
Setup for Mode 60.....	E-77
X Input Configuration .....	E-77
Program Example: Filtered Inputs .....	E-78
<b>Appendix F: PLC Memory</b>	
<b>DL06 PLC Memory.....</b>	<b>F-2</b>
Non-volatile V-memory in the DL06.....	F-3
<b>Appendix G: ASCII Table</b>	
ASCII Conversion Table .....	G-2
<b>Appendix H: Product Weights</b>	
Product Weight Table .....	H-2
<b>Appendix I: Numbering Systems</b>	
Introduction.....	I-2
Binary Numbering System .....	I-2

Hexadecimal Numbering System .....	I-3
Octal Numbering System .....	I-4
Binary Coded Decimal (BCD) Numbering System .....	I-5
Real (Floating Point) Numbering System .....	I-5
BCD/Binary/Decimal/Hex/Octal -What is the Difference?.....	I-6
Data Type Mismatch.....	I-7
Signed vs. Unsigned Integers.....	I-8
AutomationDirect.com Products and Data Types .....	I-9
<i>Direct</i> LOGIC PLCs.....	I-9
C-more/C-more Micro-Graphic Panels.....	I-9

## Appendix J: European Union Directives (CE)

European Union (EU) Directives .....	J-2
Member Countries .....	J-2
Applicable Directives .....	J-2
Compliance.....	J-2
General Safety .....	J-3
Special Installation Manual .....	J-4
Other Sources of Information .....	J-4
Basic EMC Installation Guidelines .....	J-5
Enclosures .....	J-5
Electrostatic Discharge (ESD).....	J-5
AC Mains Filters .....	J-6
Suppression and Fusing.....	J-6
Internal Enclosure Grounding.....	J-6
Equipotential Grounding .....	J-7
Communications and Shielded Cables .....	J-7
Analog and RS232 Cables .....	J-8
Multidrop Cables.....	J-8
Shielded Cables within Enclosures .....	J-8
Analog Modules and RF Interference .....	J-9
Network Isolation .....	J-9
DC Powered Versions .....	J-9
Items Specific to the DL06 .....	J-10

## Appendix K: Introduction to Serial Communications

<b>Introduction to Serial Communications</b> .....	K-2
Wiring Standards.....	K-2
Communications Protocols.....	K-3
DL06 Port Specifications.....	K-5
DL06 Port Pinouts .....	K-5
Port Setup Using <i>DirectSOFT 5</i> or Ladder Logic Instructions.....	K-6
Port 2 Setup for RLL Using K-Sequence, <i>DirectNET</i> or MODBUS RTU .....	K-7
K-Sequence Communications.....	K-10
<i>DirectNET</i> Communications .....	K-10
Step 1: Identify Master Port # and Slave #.....	K-10
Step 2: Load Number of Bytes to Transfer.....	K-10
Step 3: Specify Master Memory Area.....	K-11
Step 4: Specify Slave Memory Area .....	K-12
Communications from a Ladder Program.....	K-13
Multiple Read and Write Interlocks.....	K-13
MODBUS RTU Communications.....	K-14
ASCII Communications.....	K-14